

FIG. 1




FIG. 2

ERROR INFORMATION

| CHANNEL | FREQUENCY ERROR |
|---------|-----------------|
| 1       | 100 kHz         |
| 2       | 130 kHz         |
| 3       | 140 kHz         |
| 4       | 160 kHz         |

FIG. 3

ERROR INFORMATION

| CHANNEL | FREQUENCY ERROR | OFFSET AMOUNT |
|---------|-----------------|---------------|
| 1       | 100 kHz         | 100 kHz       |
| 2       | 130 kHz         | 0 kHz         |
| 3       | 140 kHz         | 50 kHz        |
| 4       | 160 kHz         | 150 kHz       |

FIG. 4

